



FV-707 DM
 PLL UNIT

PB-2122(NO.20..)

MSB
 C158-C170
 470P X 13




FV-707 DM
CIRCUIT DIAGRAM



D01~D14 : 1S15

J06 +3V(BATTERY)



1~D14; 1S1555